

# Inflatable Take-Down Instructions

- 1) Check for any loose items left in the Inflatable. (Sweep or vacuum where appropriate.)
- 2) Turn off blower and unplug. Disconnect the blower from the inflation tube.
- 4) Open zipper to allow air to escape and the inflatable to deflate. Deflation time vary.

## **How to Roll an Inflatable:**

- 1) Fold all material toward the middle of the inflatable and find the bottom seams (edges).
- 2) Fold one side halfway and repeat for opposite side.
- 3) Take one side and fold on top of the other side making the width 3-4 feet wide.
- 4) Tuck in any extra material. (Leave inflation tube out to allow air to escape as you roll)
- 5) Push air out of the inflatable by walking on the inflatable towards the inflation tube/zipper end.
- 6) Begin rolling from the opposite end of the inflatable tube/zipper. Doing so pushes air to escape as you roll. Roll as tightly as possible. Keep the roll lined up, tuck any in extra material, and do not allow any part of the roll to sag. Loose rolls are difficult to move. Take your time and roll it tight!
- 7) Once rolled – lift one end and place strap underneath. Tighten strap. Tuck in Inflation Tube and any extra material. Place in bag.

If you have any questions please call 215-256-4444.

